

Product profile

SF61B

Rugged 2D Pocket Scanner



SPEED

Compact form factor and available quick attach/release system enable rapid, on-demand scanning



SCANNING

Includes the industry's fastest 2D imaging technology for snappy, omni-directional scanning



RADIO

Bluetooth wireless easily pairs with iOS®, Android® and Windows Mobile® devices



RUGGED

Tested to withstand 26 drops to concrete from 2 m (6.5 ft) and rated IP65 for protection from liquid and dust ingress



BATTERY

Field-replaceable battery lasts well beyond a full shift, even in scan-intensive applications

Designed to provide the highly mobile worker with performance scanning in an extremely compact and rugged package, the SF61B integrates with existing data capture workflows and—with embedded Bluetooth wireless—easily pairs with iOS, Android and Windows Mobile smartphones and tablets. With its unique form factor and magnetic quick attach/release system, workers can accomplish their data collection tasks with more efficiency, safety and agility than ever before.

Traditional gun-shaped scanners weren't made for the worker on the go. To address this, we designed the SF61B so that it can be quickly accessed or securely stowed away as needed. A magnetic quick-disconnect system and variety of smart accessories, like wrist straps and belt loops, make it easy to rapidly access the device when needed—and just as quick to securely stow away when unencumbered use of both hands is needed.

Despite its compact size, the SF61B packs the same high performance 2D imagers as our full-size handheld scanners. With unmatched motion tolerance (up to 500 in/sec) and omni-directional reading capability, the SF61B keeps up with your workers on the go by delivering incredible scan speed at any angle. The addition of

VESTA, our patented scanning algorithm, increases read range when scanning the most common 1D codes. Advanced imaging capabilities—such as data parsing, multi-code reading, and image/video capture—are built-in and make SF61B an even more flexible data capture tool.

The robust scanning performance of SF61B is complemented with equally impressive communication and battery performance. An integrated Bluetooth Class 1 radio enables wireless communication at ranges up to 100 m (325 ft), and the field-replaceable lithium-ion battery lasts well beyond a full shift, even in the most scan-intensive applications. The SF61B offers performance characteristics commonly found in full-size scanners, at just a fraction of their size and weight.

Don't mistake the SF61B's small size for fragility. It carries an IP65 rating against liquid and solid particle ingress, making it dust-tight and capable of withstanding direct water spray-downs. Like our SR61 ultra-rugged handheld scanner, the SF61B can survive 26 drops to concrete from a distance of 2 m (6.5 ft) over a wide operating temperature range. This ruggedness, combined with a standard three-year warranty, results in decreased total operating costs over the life of the device.

Physical Characteristics

Dimensions with Magnet End-Cap (LxWxH):

15.6 cm (6.1 in) x 4.6 cm (1.8 in) x 3.9 cm (1.5 in)

Dimensions with Ring End-Cap (LxWxH):

16.0 cm (6.3 in) x 4.6 cm (1.8 in) x 3.9 cm (1.5 in)

Weight: 184 gm (6.5 oz)

Electrical Specifications

Battery: Lithium-ion rechargeable (2,600 mAh)

Battery Life¹: 28,000 scans (1D) or 25,000 scans (2D), with 1 scan every 4 seconds²

Recharging Time: 3 hours

1 Battery life varies depending on ambient temperature, ambient light and battery life.

2 Typical number of scans possible without a battery recharge, in a typical office environment (250 lux) at ambient temperature.

Bluetooth Radio

Type: Bluetooth Class 1 v2.1+EDR

Frequency: 2.4 GHz with Adaptive Frequency

Hopping Range: 100 m (325 ft) in open space, 30 m (100 ft) in typical work environment

Profiles: HID, SPP

Connectivity

Operating System Compatibility: Apple iOS[®]; Google Android[®]; Microsoft Windows[®] XP, Vista, 7, 8

Scan Technology

SF61BHP: Intermec 2D Imager with Laser Aimer (EA30)

SF61B2D: Intermec 2D Imager with LED Aimer (EA31)

SF61B1D: Intermec Linear Imager (EV14+)

Reading Performance

Maximum Code Resolution:

1D: 4 mils

2D/HP: 6.6 mils

Print Contrast:

20%

Scan Rate: 1D: Up to 200 scans/s

Motion Tolerance:

HP: Up to 500 in/s

2D: Up to 400 in/s

User Feedback

- Indication LED
- Configurable Buzzer
- Configurable Vibrator (Haptic Feedback)

Bar Code Symbolologies for 1D Model (SF61B1D)

Codabar, Code 11, Code 39, Code 93/93i, Code 128 / GS1-128, EAN/UPC, GS1 DataBar Limited, GS1 Composite (linear only), GS1 DataBar Expanded, GS1 DataBar Limited, GS1 DataBar Omnidirectional, GS1 DataBar Stacked, Interleaved 2 of 5, Matrix 2 of 5, MSI, Plessey, Standard 2 of 5, Telepen

Bar Code Symbolologies for 2D Models (SF61BHP/2D)

All above symbolologies supported by 1D model plus the following: DataMatrix, QR Code, Micro QR, PDF417, Micro PDF417, Aztec, Maxicode, Han Xin, Codablock A, Codablock F, GS1 Composite, TLC 39, and Postal Codes (Australian Post, BPO, Canada Post, Dutch Post, Infomail, Intelligent Mail, Japan Post, Planet, Postnet, Sweden Post)

Environment

Operating Temperature: -20°C to +50°C (-4°F to +122°F)

Storage Temperature: -40°C to +70°C (-40°F to +158°F)

Charging Temperature: 0°C to 45°C (32°F to 113°F)

Relative Humidity: 5 to 95% non-condensing

Drop: 26 drops from 2m (6.5 ft.) to concrete

Environmental Rating: IP65

Ambient Light: 0 to 100,000 lux

Regulatory Approvals & Compliance

1016SP01B (SF61B)

Safety: cULus Listed, CDRH, CE

EMC: classB-FCC/ICES, CE

Radio: FCC, IC, CE, IDA (Singapore), IFETEL (Mexico), A-Tick

Other: BIS, ANATEL, EAC, NTC, SIRIM, MSIP, EU Directives-WEEE, ROHS, Batteries & Accumulators, Packaging & Waste Packaging

Standard Warranty

Three year standard warranty, with extended protection available through Intermec Medallion Support Services.

Accessories

View the SF61B Accessory Guide for complete details.


- Charger, Single-Bay*
- Charger, Quad-Bay*
- Charger, Vehicle
- End Cap, Ring with Wrist Strap
- End Cap, Magnet with Belt Loop
- FlexDock Cup, Dual-Charge
- FlexDock Cup, Quad-Charge
- Holder, Belt Clip*
- Holder, Chest Strap
- Power Adapter, AC
- Power Adapter, USB
- Wireless Base Station*

* These accessories, originally developed for SF51, are also compatible with SF61B.

Typical Reading Distances³

SF61BHP			
Symbology	Density	Minimum Distance	Maximum Distance
Code 39	0.1 mm (4 mils)	5 cm (1.97 in)	22 cm (8.66 in)
	0.125 mm (5 mils)	4 cm (1.57 in)	27 cm (10.63 in)
	0.5 mm (20 mils)	6 cm (2.36 in)	71 cm (27.95 in)
	1 mm (40 mils)	14 cm (5.51 in)	125 cm (49.21 in)
EAN/UPC	0.33 mm (13 mils)	5 cm (1.97 in)	47 cm (1.50 in)
PDF417	0.25 mm (10 mils)	4 cm (1.57 in)	27 cm (10.63 in)
	0.38 (15 mils)	4 cm (1.57 in)	36 cm (14.17 in)
DataMatrix	0.25 mm (10 mils)	6 cm (2.36 in)	22 cm (8.66 in)
SF61B2D			
Symbology	Density	Minimum Distance	Maximum Distance
Code 39	0.1 mm (4 mils)	4 cm (1.57 in)	19 cm (7.48 in)
	0.125 mm (5 mils)	4 cm (1.57 in)	24 cm (9.45 in)
	0.5 mm (20 mils)	6 cm (2.36 in)	67 cm (26.38 in)
	1 mm (40 mils)	14 cm (5.51 in)	117 cm (46.06 in)
EAN/UPC	0.33 mm (13 mils)	5 cm (1.97 in)	41 cm (16.14 in)
PDF417	0.25 mm (10 mils)	4 cm (1.57 in)	25 cm (9.84 in)
	0.38 mm (15 mils)	4 cm (1.57 in)	36 cm (14.17 in)
DataMatrix	0.25 mm (10 mils)	5 cm (1.97 in)	19 cm (7.48 in)
SF61B1D			
Symbology	Density	Minimum Distance	Maximum Distance
Code 39	0.1 mm (4 mils)	6 cm (2.36 in)	23 cm (9.06 in)
	0.125 mm (5 mils)	5 cm (1.97 in)	25.5 cm (10.04 in)
	0.25 mm (10 mils)	5 cm (1.97 in)	32.5 cm (12.80 in)
	1 mm (40 mils)	10 cm (3.94 in)	87.5 cm (34.45 in)
EAN/UPC	0.33 mm (13 mils)	5 cm (1.97 in)	33 cm (12.99 in)

³ The reading distances for each scanner are typical distances measured from the front end of the scanner bezel in an office environment (200 lux) with extended reading range activated (if applicable).



Note: This warning applies only to SF61BHP (EA30) models.

North America

6001 36th Avenue West
Everett, Washington 98203
Phone: (425) 348 2600
Fax: (425) 355 9551

South Latin America

Brazil
Phone: (+55) 1137116770
Fax: (+55) 1155026780

Europe, Middle East & Africa

Reading, United Kingdom
Phone: (+44) 118 923 0800
Fax: (+44) 118 923 0801

Asia Pacific

Singapore
Phone: (+65) 6303 2100
Fax: (+65) 6303 2199

Media Sales

EMEA: (+31) 24 372 3167
USA: (513) 874 5882
http://intermec.custhelp.com

Sales

Toll Free NA: (800) 934 3163
Toll in NA: (425) 348 2726
Freephone ROW:
00800 4488 8844

OEM Sales

Phone: (425) 348 2762

Customer Service & Support

Toll Free NA: (800) 755 5505
Toll in NA: (425) 356 1799
EMEA: intermec.custhelp.com

Internet

www.intermec.com

Worldwide Locations

www.intermec.com/locations